



Drill feed-thru hole for cable on mounting surface 77 3/4" above the finished floor





RJ-11 Connection Male to Female Connection

## Completing the housing installation

Remove the front face plate of the housing by removing the five white oval head 6/32 screws that secure the plate to the housing.

Feed the wire through the 3/4" hole in the back of the housing. Mount the housing to the gimble mount using the 1/4-20 Allen head screws at the top and bottom. Place the silver washers between the housing and the gimble mount. Then place the Allen head screw with the black washer through the gimble and silver washer. Screw down and secure top and bottom

Make the RJ-11 male and female connection. Replace the face plate with the five white 6/32 screws. Adjust the camera housing right or left to acquire the proper field of view for the installation. Tighten down the Allen head screws and verify that the housing is in position and secured.